

ATTACHMENT VII-2

**Ground-Water Sampling and Field Analysis
Standard Operating Procedures**

I. INTRODUCTION.....	1
A. GENERAL STATEMENT CONCERNING FACILITY MONITORING.....	1
B. RESPONSIBILITIES OF KEY PERSONNEL.....	1
C. QUALITY ASSURANCE/QUALITY CONTROL (QA/QC)	2
II. PLANNING THE SAMPLING EVENT	4
A. PRE-EVENT PREPARATION	4
B. DAY OF SAMPLING PREPARATION.....	8
III. SAMPLING PLAN (ROUTE AND STRATEGY)	11
A. SAMPLING ROUTE	11
B. QA/QC SAMPLES	11
IV. PURGING AND OTHER SPECIFIED WELL ACTIVITIES	12
A. WELL PURGING	12
B. WATER-LEVEL READINGS	12
C. WELL-VOLUME CALCULATIONS.....	13
D. PURGING.....	15
E. DEPTH READINGS (EACH TIME A PUMP IS PULLED, BUT AT LEAST BIENNIALY COMMENCING 2010).....	16
V. WELL SAMPLING.....	18
A. FIELD ANALYTICAL PROTOCOL	19
B. PROTOCOL OF SAMPLING FOR LABORATORY ANALYSES	20
C. ENDING THE INDIVIDUAL WELL SAMPLING.....	24
D. ENDING THE SAMPLING EPISODE.....	24
E. WELL RESAMPLING	26
VI. DOCUMENTATION AND DOCUMENT CONTROL	26
A. SAMPLE CONTAINER CONTROL AND DOCUMENTATION.....	26
B. FACILITY PREPAREDNESS.....	27
C. EQUIPMENT PROBLEMS	28
D. CERTIFICATION OF COMPLETION	28
VII. OBSERVATION WELLS OR MALFUNCTIONING MONITORING WELLS	28
VIII. PUMP REMOVAL, CERTIFICATION AND REPLACEMENT	30
A. PUMP REMOVAL.....	30
B. PUMP CLEANING	30
C. REASSEMBLY.....	30
D. CERTIFICATION	31

APPENDIX A IMMISCIBLES

Attachment VII-2 Table:

GRASSY MOUNTAIN GROUNDWATER SAMPLING FIELD DATA SHEET

GROUND-WATER SAMPLING AND FIELD ANALYSES STANDARD OPERATING PROCEDURE

I. Introduction

A. General Statement Concerning Facility Monitoring

Protection of the ground water under its facilities is a critical environmental concern of the Permittee. This procedure shall provide for efficient, accurate and representative sampling of the ground water beneath the Grassy Mountain Facility, and subsequent analysis of those samples. Other non-routine sampling events may also be covered by this document.

Throughout this document, the term "The Laboratory" will be used. "The Laboratory" is expressly stated to mean the Utah certified lab used for analyses of environmental samples.

B. Responsibilities of Key Personnel

Management of the ground-water monitoring program is the responsibility of the Grassy Mountain Facility Manager. He will coordinate this effort utilizing personnel from any or all of the following: the Facility, Corporate headquarters, other divisions or companies of the Corporation, consultants, temporary agencies and The Laboratory. The actual sampling teams may be composed of representatives from any or all of these entities. There will be a person designated as the Facility Technical Representative (FTR) to perform specific duties as noted.

Sampling Team and/or Purging Team:

The sampling and/or purging team(s) are responsible for the actual field activities of the sampling episode. The Facility Technical Representative shall act as the team coordinator. At the beginning of the episode, an event coordinator shall be determined. Individual team members shall be composed of appropriately trained persons. The sampling and purging teams will each be comprised of a minimum of two members. A single team can be used for both purging and sampling.

Each team member will have read the Groundwater Sampling and Field Analysis Standard Operating Procedure and passed a written test before sampling is undertaken. Results of the tests shall be included in the sampling event records. Field experience will be gained in stages, with

continuing supervision from one of the senior members of the group. The person(s) responsible for various documents relating to field sampling (Document Control Officer) will become familiar with the SOP and receive instruction from the senior representative prior to the event.

Team Leader(s):

This person(s) will be the supervisor for each individual purge or sampling team. Specific responsibilities shall include team adherence to protocol, documentation management for their team and assignment of team members to specific tasks.

Team Member(s):

These individuals shall accomplish required tasks as assigned by the team leader.

C. Quality Assurance/Quality Control (QA/QC)

Detailed QA/QC procedures are a significant part of all aspects of sample collection, sample preservation, sample shipment, analytical procedures and chain-of-custody control. QA/QC for sample collection, sample shipment and chain-of-custody control shall be as follows:

1. Sample preservation, sample sizes and holding time requirements shall be updated by the laboratory prior to each event to make sure the most current method requirements are used. This list, an example of which is Attachment VII-3, Table 4, is provided to the sampling team.
2. Analytical methods are shown in Attachment VII-3.
3. Sample Preservation and Transportation Methods
 1. Preservation additives can be added at the sampling site or can be added by the laboratory prior to the sampling event.
 2. Both the persons handling the sample and the sample itself shall be protected from damage. The laboratory safety manual, the analytical method and site safety requirements shall provide guidance for the safe handling of samples. All samples shall be handled with extreme care.
 1. Sample containers as shipped from the Laboratory for field use shall be packed to prevent contamination and/or damage.
 2. Sample containers as received at the facility shall be

- inventoried and protected to prevent contamination and/or damage. The sample shipping container can be used to store the sample containers at the site, move the sample containers to the sample site and to hold and ship the sample containers after sampling.
3. After the sampling event, all samples shall be returned to the laboratory in coolers packed so as to prevent damage and to maintain the appropriate temperature.
 3. Samples generated during the sampling event shall remain under the control of the sampling team or shall be stored in a secure (locked) location. Chain-of-custody documentation will be initiated by the sampling team. Custody shall be transferred to the shipping company, when used, at the time of shipping through use of the shipping documentation. Receipt of the samples at the Laboratory shall be documented on the chain-of-custody seal. All sample transfers, except during shipping via an overnight delivery service, shall be documented on a chain-of-custody form that shall be retained by the laboratory as part of the internal documentation package.
 4. The following information shall be included on chain-of-custody forms:
 1. Sample location;
 2. Sample tracking identification;
 3. Name of sampler(s);
 4. Signature of sampler(s);
 5. Date of sample collection;
 6. Time of sample collection;
 7. Type of sample;
 8. Number of sample containers;
 9. Analysis requested;
 10. Space for additional chain-of-custody transfer signatures;
 11. Laboratory name and location;
 12. Additional sample tracking information as deemed necessary.
 5. The permittee shall ensure that the laboratory follows procedures to track sample receipt, maintain log-in

procedures and other documentation, which shall include chain-of-custody records from sample receipt to sample disposal.

2. Samples at the laboratory shall remain in secured storage areas from sample receipt until sample disposal. Removal and return of samples shall be documented on Internal Chain-of-Custody Logs. Extracts and/or digestates from sample preparation routines will be stored in appropriate areas. All access doors to storage areas shall be controlled to prevent unauthorized access.
3. A master file containing the original shipping documentation (if used), chain of custody, sample receipt, and approved laboratory reports shall be maintained and archived for at least three years.

II. Planning the Sampling Event

A. Pre-event preparation

1. Scheduling:

The final sampling event schedule shall be prepared by the Facility Technical Representative. The following tasks will be accomplished prior to actual field sampling activities:

- a. Appropriate staff from the Laboratory shall gather, label and package the appropriate sample containers for the sampling event, as per the analytical protocol. Preservatives for all analyses, can be added at this time. Coolers and containers shall be shipped with all other needed analytical materials. Checklists (as enclosed) which document pre-sampling event activities will be signed and maintained with the sampling event documentation .
- b. The Facility Technical Representative or designee shall gather all required instrumentation needed for the field analytical data, which generally includes:
 - Depth Sounder
 - Turbidity meter
 - Field pH meter,

- Field conductivity meter,
- Field thermometer,
- Organic Vapor Analyzer

As the field instrumentation is gathered, each instrument shall be confirmed to be clean and operational. Calibration and testing procedures outlined by manufacturers specifications shall be followed. A calibration and testing checklist shall be maintained for each piece of equipment. Any equipment needing repair, recharging or battery replacement shall be evaluated and corrected at this time so all needed equipment shall be operational during the days of sampling. All standards to be used for the sampling episode shall be confirmed to be available and in appropriate condition for use during the sampling event. As much as practical, duplicate instrumentation shall be available at the facility in case of breakage or malfunction.

- c. The sample containers shall be inventoried at the facility to assure that all appropriate sample containers have been received in acceptable condition. Missing or broken containers shall be reordered from the laboratory or vendor as needed.
- d. The Facility Technical Representative, or designee, shall assure the other needed equipment is collected:
 - o Safety equipment including protective gloves, safety glasses, respirators and chemically resistant coveralls for each team member, when required by corporate and/or facility health and safety policy.
 - o Graduated wastewater buckets, graduated cylinder or beaker, and timing device capable of measuring to the nearest second.
 - o Appropriate waste container labels
 - o Sample containers for field analytical determinations.
 - o Deionized/distilled water shall be available from the

Laboratory or from the facility for cleaning purposes and the collection of QA/QC blank samples. At least one complete trip blank field blank and equipment blank using this DI water shall be collected for each annual sampling event.

- o Well controller for dedicated well pumps. The unit shall be confirmed to be working as per the manufacturer's specifications.
 - o Tarpaulin, plastic sheets, or other nonporous material (ground cloth) for use as the sampling surface at individual well locations.
 - o Waste container for purged well water and other water discarded during the sampling event (this water shall be managed according to section IV.D.3. of this procedure). If the well is inside the fenced perimeter of the facility, the waste container can be left on the well concrete apron or on a pallet pending disposition of the water. One or more containers can be used for purge water from wells outside the perimeter fence and brought inside the fence for management.
 - o Appropriate sampling vehicle. It will be confirmed that appropriate vehicles will be available for the sampling episode. It is emphasized that any possible surface upon which a sample could be placed should be clean.
- e. Documentation shall be maintained by each team describing performance of all procedures and tasks. Notes are to be taken during all purging and sampling related activities describing the sequence of events. This documentation shall be maintained in a combination of field notebooks, field data sheets, field forms, and checklists. At a minimum, each team shall maintain a field notebook. Field notebooks are to be constructed of bound, water-resistant pages. Notes are to be entered using non-erasable ink. Data can be transferred from field notebooks to other required field data

sheets and forms at a later time and date. Information may be recorded in more than one location. Data can be entered simultaneously in a field notebook and a data sheet. Duplication of record keeping is encouraged. Information recorded during purging and sampling related activities shall include, but not be limited to the following:

- Identification of sampling location or monitoring well, condition of well, locked or not, any evidence of tampering, and presence of standing water in the vicinity.
- Meteorological information including temperature, wind direction and velocity, barometric pressure, and general conditions and time of all measurements. These measurements shall be recorded at least twice daily, once in the morning and once in the afternoon.
- Sample team members and all observers.
- Water-well depth information.
- Well Purging information and calculations.
- Organic vapor analyzer reading.
- Results of all immiscible checks.
- Specific sampling information for each well including turbidity measurements.
- Sample distribution.
- Instrument calibration information
- Variations from the SOP and the reasons for the variations. Documentation of variations from the SOP does not relieve the facility of any obligations to perform procedures as described in the permit.

A sample of a field data sheet is included as part of this

attachment. Revisions to this form can include additional information or reformatting.

B. Day of Sampling Preparation

1. Field instrumentation shall be validated for use daily prior to going into the field. Manufactures specifications will be followed for the calibration and maintenance of all instruments. Instrument preparation protocols include the following:
 - o pH Meter: The pH meter will be calibrated using a three buffer system to assure accuracy and precision. The two primary calibration buffers should bracket the range of anticipated values. The third buffer should be used as a calibration check only (unless the meter can be calibrated using all three buffers). Standard buffers shall be available over the range of pH 4 to pH 10. A minimum of two three-buffer calibrations, as explained above, shall be performed daily. The calibration shall be conducted outside of facility buildings at ambient temperatures.
 - o Conductivity Meter: The conductivity meter shall be capable of measuring specific conductances up to at least 100,000 umhos/cm. The meter shall be calibrated at least twice daily using two standards. One standard shall be used to set the calibration while the second standard reading shall be recorded for reference (unless the meter allows a two standard calibration). These two calibrations shall be performed outside of facility buildings at ambient temperatures prior to use in the field. The two calibration standards shall bracket the range of anticipated field readings based upon previous sample results.
 - o Depth Sounder: The water depth sounder shall be confirmed to be working as per manufacturer's specifications (See Appendix B). An Interface Probe can also be used as a sounder.
 - o Organic Vapor Analyzer: The Organic Vapor Analyzer shall be calibrated using the manufacturer's specifications. Any detector can be used as long as it provides a quantitative

measurement of airborne organic vapors to the nearest 1 ppm. Calibrations shall be performed at least once per day prior to use in the field.

2. Health and Safety

Prior to entering the field, each piece of safety equipment shall be checked for appropriate fit and applicability:

- o Other health and safety aspects shall be considered in accordance with the facility health and safety requirements.
- o Respirators shall be of the appropriate type as designated by safety requirements and/or the facility safety representative. Respirators shall be carried by each team member during the sampling and will be worn any time it is required by facility safety rules. Respirators will also be worn at any time when the judgment of a team leader dictates. A reading of more than 10 ppm, using the Organic Vapor Analyzer, in the air space above the monitoring well will be cause for immediate concern. Field experience based on previous sampling episodes, coupled with analytical results, indicates no immediate hazard exists (such as sulfides). Specific safety precautions shall be addressed by the facility safety representative.
- o Gloves shall be worn by all team members participating directly in sample collection and preservation tasks. As a minimum, disposable latex gloves or equivalent shall be worn. Gloves shall be changed as necessary to prevent cross contamination, maintain cleanliness and to assure safety. Gloves shall particularly and specifically be changed between wells, and if they become soiled with any possible contaminant.

3. Sample Containers and Coolers

Prior to leaving for the field, sample containers shall be rechecked to assure that there is a full set for each well properly marked and labeled. Ice, or other cooling agents, shall be added to the coolers to aid in preserving the samples. The ice chests shall be managed

in the field to minimize temperature changes. Following sample inventory, and prior to sample shipment, ice or other cooling agents shall be added to the shipping containers to ensure a cool environment during shipping.

4. Documentation Package

The following documentation shall be maintained:

- o Field notebook(s)
- o Field data sheets
- o Chain-of-custody forms
- o "Measurement of Ground-water Levels" form or equivalent

Appropriate writing tools, such as several ballpoint pens and indelible markers, shall be included as part of the documentation package.

5. Vehicle Use and Packing

The designated vehicle to be used for the sampling episode shall be cleaned and loaded so that each item of equipment is readily available at time of use. Vehicle inventory shall include:

- o Sample coolers
- o Field analytical instrumentation
- o Wastewater bucket for purging
- o Depth sounder, probe or Interface Probe
- o Deionized/distilled rinse water for decontamination
- o Well pump controller
- o Sample containers and glass bottles

III. Sampling Plan (Route and Strategy)

A. Sampling Route

The sampling route shall be based on first, sampling of the wells with the least potential for contamination and proceeding to the wells with the highest potential for contamination. The basic strategy is that background wells are to be monitored prior to down gradient wells and that wells outside of the controlled area be sampled prior to wells inside the controlled area. If leachate sumps are to be sampled, they will be last on the schedule. Wells known to be slow to recover will be purged at an appropriate time to assure timely completion of the episode. Based on this strategy, a route plan for the sampling team can be developed. The route shall be confirmed by the Facility Technical Representative and should be kept as part of the sampling SOP documentation. The route can change based upon operational requirements.

During this event, Utah Department of Environmental Quality, Division of Solid and Hazardous Waste shall be invited to observe. The dates proposed are target dates and final schedules for sampling shall be adjusted to maintain compliance with all of the Grassy Mountain Facility permits and approvals.

B. QA/QC Samples

Sample duplicates, field blanks, equipment blanks, and trip blanks shall be collected during sampling events as QA/QC samples. All QA/QC samples shall be collected with the same care and treated as regular samples.

Duplicate samples shall be collected from a minimum of ten percent (10%) of the sampled wells. Each duplicate sample shall be analyzed for the same parameters as the original sample. Duplicates shall be collected by alternating the filling of bottles between the sample and the duplicate sets. Each duplicate will be labeled to disguise the sample location from the laboratory. The location and identity of each duplicate sample shall be maintained in the field documentation.

A least one complete field blank will be collected during each week of a regularly scheduled sampling event. One VOA field blank shall be collected daily when VOA samples are being collected. Field blanks shall be collected at a sample location (i.e. wellhead) or in the immediate

vicinity of facility activity (such as near an active cell).

Trip blanks will originate at the Laboratory, shall remain with a shipment container, and shall be submitted to the laboratory with sample shipments for analysis. At a minimum of one trip blank for every two days of shipping shall be submitted for VOA analysis when VOA samples are being collected.

An equipment VOA blank shall be obtained from the well water level probe at the beginning of each regularly scheduled sampling event.

IV. Purging and Other Specified Well Activities

A. Well Purging

At a minimum, three well casing volumes shall be purged prior to obtaining a sample for laboratory formal analysis (see calculations section). After the last well casing volume is purged, pH, and conductivity shall be measured. Wells with low rate of recovery shall require special procedures. Wells shall be defined as being dry when less than 150 ml/minute is obtained during pumping. Wells which, after purging, cannot provide adequate volume for samples shall be purged dry and allowed to recover for about 24-hours (or less, if the water level has recovered sufficiently). Following this recharge cycle, as much sample as possible shall be obtained. The well shall be allowed to recover additional 24-hours (or less if the water level has recovered sufficiently) should additional water be needed for sample collection. All wells except low recovery wells shall be sampled the same day that they are purged.

B. Water-level Readings

Water-level readings for each well shall be taken electronically using an electronic depth meter or interface probe. Water levels shall be measured and recorded during each sampling event, or as required by regulations or permit, but at least each quarter. The Facility Technical Representative, or designee, shall take these measurements. Gloves shall be worn to minimize the potential for contamination. Water-level readings are taken in concert with review of each well using the following order of activities:

1. After arrival at the well, environmental and site information per Section II.A.1.e shall be recorded. Background Organic Vapor

Analyzer readings shall be obtained and recorded.

2. A team member shall remove the lock and open the steel top. They shall remove the plastic plug in the well cap, taking care that no dirt or foreign matter is dropped into the well. A check of the well head in the breathing area shall be taken with the Organic Vapor Analyzer and recorded. A reading greater than 10 ppm in the air space shall invoke the safety consideration identified in the "Health and Safety" section, II.B.2. A team member shall rinse and wipe the probe of the electronic depth meter with deionized/distilled water. The probe shall be slowly lowered into the well until the meter indicates that water has been reached. The depth at which the water was encountered shall be measured from a surveyed datum and recorded. (The meter shall be read to the nearest 0.01 ft.). The probe shall be raised until it is no longer in the water. Lower the probe again until the meter indicates that water has been reached and enter the value in the field log book. If the values do not agree within 0.02 ft., the steps shall be repeated as above until the two readings agree within 0.02 ft. (record all values).
3. The probe shall be raised from the well, cleaning the immersed portion of the cable and rinsing the probe thoroughly with deionized/distilled water. Replace the probe and meter in the protective sleeve or other protection.
4. Continue with the Section D purging operation or secure the well so the team can then proceed to the next well in the circuit.

C. Well-volume Calculations

The volume of water to be removed from the well for purging can be calculated from the following formula:

Water volume to
be purged (gal) = (Casing Length in Ft - Depth to
Water in Ft) * X * 3

Where: X = 0.16 for 2 inch wells¹

¹The volumes/foot values given are nominal values using the assumption that the actual casing diameter is exactly equal to the stated size. Variations between casing types, manufacturers, production runs, temperatures, handling conditions, etc., will make the actual volumes slightly different from those stated. These minor differences will make no

X = 0.65 for 4 inch wells¹

X = 1.47 for 6 inch wells¹

(Rounded to two decimals, only)

To convert gallons to liters, multiply by 3.785.

effective difference in the quality of samples actually retrieved.

Values for additional casing sizes are available and values can change as construction materials vary.

It will be noted on the field data sheet or "Measurements of Ground-water levels" form if there is a significant difference between the current water elevation and/or well volume calculation and the historical value. A table including the most recent well depth measurements shall be made a part of the facility log records. The table shall be updated prior to each regularly scheduled sampling event.

D. Purging

Whenever a well is purged, gloves shall be worn.

1. Obtain and record background Organic Vapor Analyzer readings, unless this has been done previously during the current sampling event.
2. Open the well and check for vapors at the well head and in the breathing zone using the Organic Vapor Analyzer. In the absence of vapors, proceed. If vapors greater than 10 ppm are measured in the breathing area, follow procedures as found in the health and safety section II.B.2.
3. Each well has a dedicated pump. Specifications, details and operational procedures are included at the conclusion of this protocol. Using the established total volumes to be removed from the well, the following protocol shall be used to purge each well.
 - a. Connect the well pump control unit to each well.
 - b. Start the pump and remove as much water from the well as required based on the well-volume calculation. Collect purge water in an appropriate container to validate purge volumes and to minimize any contamination of the ground or well apron by the purged water.
 - c. Observe the purge water for evidence of immiscibles and note the results on the field data sheet.
 - d. Note the amount removed from the well on the field data sheet.

- e. All purged water shall be placed in a container and managed as hazardous waste. Initial management is limited to labeling containers and handling labeled containers as hazardous waste. It shall then be managed in one of the following ways:
 - 1. Regardless of previous or current analytical results, it can be solidified and disposed of in RCRA permitted disposal units or disposed of as leachate. This does not include any assignment of hazardous waste codes or imply that any of the Land Disposal Restrictions, regulatory prohibitions or restrictions apply to groundwater.
 - 2. It may be stored until the analytical results are received from the sampling event and if those results show no constituents above the critical level, the drum can be opened and the water allowed to evaporate or sprayed onto the ground away from the well or solidified and disposed of in the landfill or mixed with and disposed of as leachate.
- f. If the dedicated pump is non-operational, the well shall be bailed using the procedures, including cleaning, and representative blanks, outlined in Section VII (observation wells and malfunctioning monitoring wells).
- g. Cap and lock the well and proceed to the next well according to the schedule or proceed with sampling.

E. Depth Readings (Each time a pump is pulled, but at least biennially commencing 2010)

Depth readings shall be measured for each well using a special electronic depth sounder (Interface Probe). This procedure shall not be performed during the actual sampling event unless a pump must be pulled during the event. The depth readings shall be taken in concert with review of each well, as per the following order of activities:

- 1. After arrival at the well, note and record all required environmental and site information as required by section II.A.1.e.

2. Obtain and record background Organic Vapor Analyzer (OVA) readings.
3. The designated team member will proceed as follows:
 - a. The well shall be opened and checked for vapors at the well head and in the breathing zone using the Organic Vapor Analyzer. In the absence of vapors, proceed. If vapors greater than 10 ppm are measured in the breathing area, follow procedures as found in the health and safety section II.B.2. Grasping the PVC cap with both hands, gently remove the cap and lift upwards. Since the pump and tubing are attached to the lid, the pump will be removed as the lid is raised. Carefully coil the tubing and place the lid, coiled tubing, and pump into a large, clean, plastic, disposable bag. Close and seal the top of the disposable bag containing the pump and tubing. Care shall be taken to not let the lid, tubing, or pump touch anything other than the inside of the bag while being placed in the bag.
 - b. Carefully rinse and wipe the probe before well measurements are taken. Slowly lower the Interface Probe (copy of operation manual at the end of this protocol) into the well until it contacts the water or an immiscible layer is contacted. Record all fluid level readings to the nearest .01 feet. Obtain 2 consecutive fluid readings within .02 feet and record. After the fluid level readings are recorded, continue to lower the probe until it gently touches the bottom of the well. Record the depth when tension in the cable is relieved as the probe touches the bottom of the well. Raise the probe above the bottom and then lower it again to the bottom to take a second reading. The readings taken are recorded to the nearest 0.01 ft. as measured from a surveyed datum.
 - c. If a LNAPL (Light Non-Aqueous Phase Liquid) or a DNAPL (Dense Non-Aqueous Phase Liquid) is encountered, record the occurrence of such phases. Arrangements shall be made to sample the well after notification to the Director.
 - d. Slowly remove the probe from the well, carefully rinse and wipe both the immersed portion of the cable and probe with

deionized/distilled water as it is removed, ensure the wire or probe never touches the ground or anything outside of the well. If a LNAPL or DNAPL were encountered the decontamination procedure shall include a laboratory detergent rinse followed by deionized/distilled water. In the event these procedures are not effective, then a senior team member shall decide to use a acetone/hexane rinse which will precede the detergent and deionized/distilled water. The acetone/hexane rinse shall not be recommended except in extreme circumstances. These procedures can be performed in the field or upon returning to the laboratory to decontaminate the cable and probe.

- e. Remove the pump from the bag and thoroughly rinse both the pump and the first few feet of tubing with deionized/distilled water. After rinsing, insert the pump and first few feet of tubing back into the well. Prior to reinserting the remaining tubing, they shall be rinsed with deionized/distilled water or wiped with disposable wipes. Gently lower the pump and tubing back into the well. Abrupt actions could separate the components. Securely push the cap back onto the well stem making sure that the cap is flush with the top of the PVC casing. Record the condition of the pump and any other observations on the field data sheet or in the log book.
- f. Minor maintenance and cleaning of the pump can be undertaken while the assembly is accessible on the surface. Extensive maintenance or cleaning can require additional servicing or replacement.
- g. Secure the well cap and proceed to the next well in the circuit.

V. Well Sampling

Once the wells have been purged, the actual sampling shall occur. All wells except low recovery wells shall be sampled the same day they are purged. Wells with low recharge rates shall be sampled as per the protocol outlined in Section III. Steps 1 and 4 below do not have to be repeated, if sampling is part of a continuous purge and sample event, or if the well was purged on the same day

and the purge team OVA readings were below the levels of concern.

A. Field Analytical Protocol

1. Note all required environmental and site information per Section II.A.1.e. A Background Organic Vapor Analyzer reading shall be obtained and recorded.
2. A team member shall remove the ground cloth from the sampling vehicle and place it at an appropriate place near the well. The location shall be designated by the team coordinator.
3. A team member shall check and confirm calibration of the field analytical instruments.
4. Check the well with an Organic Vapor Analyzer. If this has been performed previously during the current sampling event, this does not need to be repeated.
5. Start the pump controller and allow the water to fall into the waste bucket. Observe the water in the bucket and in the samples for evidence of immiscibles and note the results on the field data sheet.

Separate samples for pH, specific conductance, and turbidity can be collected or these same analysis can be performed from the same sample.

6. pH measurement: Confirm calibration of the instrument in the field, i.e. ± 0.1 pH units using the pH 7 standard buffer. Make any adjustments as needed to meet calibration requirements. Take a sample from the well, place the pH probe into the sample, let the reading stabilize, and record. Remove the probe from the water and reimmerse the probe into the sample to obtain a second reading. Continue this process until consistent values are obtained. Record all readings. Wash the probe with deionized/distilled water and discard with purge water. Place the pH meter and probe in the pH meter protective carrying case.
7. Turbidity: Confirm calibration of the instrument per manufacturer's requirements. Collect a sample from the well and place in the sample cell and wipe to remove water spots and finger prints. Apply

a thin film of silicon oil over the entire surface. Put the sample cell in the instrument compartment following the operators guide. Take a reading and record the value.

8. Specific conductance: Confirm the calibration ($\pm 10\%$) of the instrument using at least one standard of specific conductance similar to the sample. Make any instrument adjustments as required to meet calibration criteria. Take a sample from the well and immerse the conductivity probe into the sample. Measure and record the value. Discard sample in the waste container, wash probe with deionized/distilled water and replace the meter and probe in the protective container. In the event of specific conductivity greater than, 100,000 umhos/cm, specific conductance shall also be analyzed by the Laboratory. All specific conductance readings, field and laboratory, shall be corrected to 25 degrees celsius.

B. Protocol of Sampling for Laboratory Analyses

1. Sample containers can come pre-labeled and/or pre-preserved from the laboratory or vendor, identifying the analyses and appropriate preservative. This is to assure proper bottle inventory during sample gathering, sending and receiving. If received without labels, all bottles shall be appropriately labeled at the facility prior to entering the field. If bottles are pre-preserved or if preserved at the time of sampling, random pH checks shall be performed to verify proper pH values for preservation.
2. Analytes, if sampled, shall be sampled in the following order and with the following precautions as required by permit conditions:

Group I

- o Volatiles
- o TOX
- o TOC

Group II

- o TOC
- o Semi-Volatiles
- o pesticides/herbicides/PCB's

- o Total Metals
- o Dissolved Metals,
- o General Parameters - TDS, TSS and Anions
- o Phenols,
- o Ammonia, Hardness,
- o Total Cyanide,
- o Total Sulfide,

NOTES:

- a. Group I analytes are flow-sensitive and shall be collected first.
 - b. Group II analytes are not flow sensitive and shall be collected next.
 - c. TOC may be collected as either a Group 1 or Group II analyte, which will be determined by the type of the sample container provided by the laboratory. Note that the collection of this analyte is not flow sensitive.
3. A list of the current requirements for types of containers, holding times, minimum acceptable volumes, and preservation methods for each sample parameter shall be updated by the laboratory and provided to the sampling team prior to each sampling event based on the analytical methods shown in Attachment VII-3, Table 4. The permittee is required to abide by this list. Attachment VII-3, Table 4, contains an example of what the list given to the sampling team will look like. Changes shall be included in the report of the event submitted to the Director.
4. Samples requiring preservatives require special handling procedures. The safest and most desirable method of preserving with an acid or base is add the preservative once the bottle is full. Random checks of sample pH will be conducted to verify proper sample preservation. The pH paper can be used for this purpose by pouring a small amount of preserved sample over the pH paper. The pH paper or pH probe shall not be directly immersed into a preserved sample bottle. All bottles shall be filled such that sufficient headspace remains for the addition of any required preservatives.

5. Flow-sensitive Analytes:

- o For volatile analyses the flow rate shall be adjusted to be at least 75 ml/min but shall not exceed 150 ml/min with the top of the sample vial located less than or equal to six (6) centimeters from the exit of the sample tube. The flow shall be timed to demonstrate the flow rate. If the flow rate is adjusted before all flow sensitive samples have been taken, the sampler shall recheck the flow rate before collecting additional flow sensitive samples. Carefully add the water to the first VOA vial. Ensure that there is no air in the sample during collection and after the cap has been placed on the vial. Place the cap on the vial, invert the vial and make sure there is no trapped air in the sample. If there is air in the sample, open the vial and add sample to displace the air. Recheck until there is no trapped air as determined by inspection. Fill the other VOA vials using the same technique. Place the vials in the cooler and continue with the next sample. Sample preservative, if directed by approved method, can be added to the sample bottle during or prior to sample collection.
- o If a TOX sample is taken, the same precautions as for VOA analysis shall be used. Fill the designated bottle. The bottle shall be filled to the top with no air trapped in the bottle. When the bottle is filled, place it in the cooler.
- o If a TOC sample is taken, use the same precautions, as for the VOA bottle. The sample shall be filled to the top with no air trapped in the bottle. The sample shall be preserved with hydrochloric acid to a pH less than 2 and placed in the cooler. TOC may be sampled as "not flow sensitive," as described below. See Note C in Section V.B.2 above.

6. Analytes that are not flow sensitive:

- o The volume of sample collected for semi-volatile organics shall be specified by the method. Fill the bottle to the level specified by the most recent method, cap and place it in the cooler. Separate sample bottles, one liter (or one quart) or larger, can be used for pesticides/herbicides/PCB's. Fill

each bottle to the neck or the level specified by the most recent method, cap and place it in the cooler as above.

- o The sample for total metals shall be taken by filling the sample container to provide sufficient sample for analysis (leaving sufficient headspace for preservative) and, if the bottle is not pre-preserved, adding nitric acid preservative, to a pH of less than 2. Close the container and place it in the cooler. If a sample for dissolved metals is desired, filtering shall be performed in the field prior to preservation using a 0.45 micron filter.
- o The container for general parameters not requiring a preservative such as anions, TSS, and TDS, is filled to provide sufficient sample volume, capped and placed in the cooler.
- o If a sample for total phenol is to be taken, the bottle shall be filled to the appropriate level (leaving sufficient headspace for preservative) and add sulfuric acid preservative until a pH of less than 2 is achieved. Cap the bottle and place the sample in the cooler.
- o If a sample for ammonia and hardness is to be taken, fill the container shall be filled to the appropriate level (leaving sufficient headspace for preservative) and add sulfuric acid preservative to a pH less than 2. Cap the bottle and return it to the cooler.
- o If a The sample for total cyanide is to be taken, the container shall be filled to the appropriate level (leaving sufficient headspace for preservative) and shall be preserved with NaOH to a pH of greater than 12. Cap the bottle and return it to the cooler.
- o If a sample for total sulfide is to be taken, the container shall be filled to the appropriate level (leaving sufficient headspace for preservative) and NaOH/zinc acetate preservative shall be added to the sample to a pH greater than 9. Cap the bottle and return it to cooler.

C. Ending the individual well sampling

When the final sample has been taken at the well site, the following procedure shall be used to secure the site and prepare the team to move to the next sampling location:

- o Remove the pump controller hose from the well pump.
- o Secure the well by replacing the cap and putting the lock in place. Make sure any protective covers or caps have been put in place and secured.
- o Repack the sampling vehicle, so that the analytical instrumentation and pump controller are readily accessible for the next well sampling.
- o Clean the surface of the ground cloth and place in sampling vehicle or carefully dispose.
- o Secure all excess ground water and rinses in a waste container for disposal.
- o Dispose of gloves used at the well site.
- o Proceed to the next sampling site on the established circuit.

D. Ending the Sampling Episode

The following protocol shall be used to complete the documentation and send the samples to the Laboratory for analyses:

- o A sampling team member shall check each cooler to make sure that all samples have been collected and are packed securely. Packaged ice, "blue ice" or other cold preservative is acceptable as a coolant. Coolers filled during the day may be left in a secure (locked) area until the end of the day.
- o An assigned sampling team member shall verify the transfer of all field analytical data to report sheets. The report sheets shall be sent to the laboratory with the samples in the courier pouch in order

to be included in the documentation report.

- o The bottles to be sent shall be compared with the chain-of-custody forms. A sampling team member shall confirm that all bottles are present, and sign the chain-of-custody forms (next page shows typical example) for each set of samples.
- o A sampling team member shall review and sign the chain-of-custody forms and make sure they are placed in the courier pouch. The courier pouch shall be placed in the cooler. If an independent carrier is used, each cooler shall be sealed with "chain-of-custody" tape.
- o The bill of lading and documentation shall be prepared to send the samples to the laboratory. If necessary an overnight delivery service shall be used to ensure that the samples will arrive at the laboratory the next day. As an option, the samples can be escorted to the laboratory where samples with short hold times can be analyzed and if necessary, the other associated samples sent to a more distant lab when hold times are not a concern.
- o An assigned team member shall remove the field analytical instrumentation, calibration standards and other standards and other analytical equipment from the sampling vehicle and stores in the appropriate place.
- o All team members shall be responsible for removal and storage of personal safety equipment used during the sampling episode. Disposal of disposable clothing shall be done in an appropriate manner according to the facility policy.
- o The sampling team as a group shall review the documentation package generated during the sampling day, making sure it is complete and transferred to the master log. The assigned person shall complete any necessary information.
- o A team member shall remove all additional equipment from the sampling vehicle and place it in the appropriate storage area.

E. Well Resampling

During sampling handling, shipments, and analysis sampling bottles may be broken. In addition sample holding times can be exceeded. As a result, additional well resampling can be required to obtain new samples. Usually, this additional sampling will require a limited number of samples to be collected for analysis.

If resampling is required, the resampling will normally be scheduled for within 14 days of discovery for missing analyses; however, if the date of discovery is within 45 days of the next regularly scheduled groundwater sampling event, the resampling may be delayed to take place during that next event. All of the procedures presented in this document will apply, including well purging and sampling. All resampling efforts will follow all applicable documentation guidelines

VI. Documentation and Document Control

Management of the documentation package is a critical aspect of the sampling, as it provides assurance that all requirements of the operational permit in relation to facility ground-water sampling and analysis are being followed, as well as providing a complete record of activities prior to and during the event. Documentation shall be processed completely and accurately.

A. Sample container control and documentation

Quality assurance of the containers used for sampling at the facilities is to assure that they meet the analytical and sampling protocols. The Laboratory shall provide the following information, if requested.

- o Date of bottle preparation and analyst preparing the bottles.
- o An inventory of the bottles including vendors name, catalog number, lot number and bottle description.
- o Statement by technician preparing bottles as to cleaning protocol used, if applicable. Most bottles are brand new. However, certain bottles will require additional cleaning based on the analytical test methods used.
- o Date of shipment to the facility including carrier and handling bill

number.

- o All of the above data shall be kept by the Laboratory Manager, or designee, in a bound notebook which is available, if needed, at The Laboratory.

B. Facility Preparedness

The following information is to be maintained by the Facility Technical Representative to confirm that the facility is ready for the sampling event. The documentation will be maintained with the other sampling documentation and be available for review and a check-off system shall be put in place to confirm that all is ready for the sampling event. Signatures of responsible personnel shall be included. Information includes:

- o Confirmation of field instrumentation operation including calibration data. If any equipment needs repair or replacement, the Facility Technical Representative shall evaluate and notify the appropriate facility personnel to evaluate the impact of this shortcoming on the scheduled sampling event.
- o Confirmation that all field analytical standards are ready for use during the pre-event calibration (to be handled in concert with the above) and at the time of the actual sampling event.
- o Confirmation that all required safety equipment shall be available for all team members at the time of the sampling event. If equipment needs to be ordered, the Facility General Manager shall be notified and be given confirmation that the equipment is on order. It will be the Manager's responsibility to determine if the lack of required safety equipment shall impact the schedule of the sampling event.
- o Confirmation that all the other required sampling equipment has been gathered and is in proper order ready for the sampling event.
- o Confirmation that the bottles have been received from The Laboratory, are in suitable condition, assure that the sealing tape on each cooler is unbroken, and have been received with any necessary paper work.

C. Equipment Problems

If an equipment malfunction occurs such that adequate samples cannot be taken, sampling will cease while the equipment undergoes repair or is replaced. Upon completion of repairs / replacement of equipment, sampling shall immediately resume where terminated. If equipment cannot be repaired or replaced the same day, the remaining samples will be taken using a teflon bailer, or sampling on the down well will be terminated and resampled in its entirety upon repair.

D. Certification of Completion

The Facility Technical Representative or designee shall be responsible for seeing that a commentary is written after the conclusion of the event which describes the sampling event, including any problems or variations from the SOP that may have occurred. The Facility Manager shall be notified when the sampling event is completed and if there were any problems or variances from the SOP.

VII. Observation Wells or Malfunctioning Monitoring Wells

Observation wells may be included in the monitoring of ground water, although they are not constructed as monitoring wells and do not have dedicated pumps. These wells shall be managed and monitored as per the established methods and procedures found in the following attachments and appendices of this document. Conversely, wells with dedicated pumps may sometimes need to be sampled with a bailer. Procedures are as follows:

- o Wells can be sampled with a PTFE bailer rather than dedicated pumps. Each well will normally have its own dedicated bailer, or will use a previously cleaned bailer using the steps identified in the procedure describing the cleaning of a contaminated bailer. If the bailer has been cleaned and is to be reused, deionized/distilled water shall be placed in the bailer and an equipment blank shall be collected for VOA and total metals as a minimum. An alternate method is to use a disposable PTFE bailer. A blank can also be collected from the disposable bailer prior to use, but it is not required.
- o Purging and sampling shall be conducted by carefully lowering the bailer down the well until it fully immerses in fluid and then returning it to the

surface. Discard the water into a waste container, if it is being purged, or into the appropriate sample container, if the well is ready to be sampled. The bailer may be manipulated by hand or a power winch, using a monofilament rope, PTFE coated wire, or single strand stainless steel wire. Extreme care shall be exercised, if a power winch is used, so the coated wireline does not come into contact with any oiled or greased mechanical parts of the winch.

- o During purging and sampling the bailer and associated sampling cord shall not be allowed to touch the ground or any potentially contaminated surface. Should this happen, the bailer and/or cord shall be decontaminated or replaced prior to use.

- o Bailers shall be kept wrapped in clean foil or suitable material and stored in a clean plastic bag, when not in use.

- o If a bailer becomes contaminated, the following procedure shall be used to clean it:
 - a.) If the bailer is heavily contaminated, the bailer shall be thoroughly washed with a strong laboratory soap such as Alconox or Hexane/Acetone. Hexane/ Acetone shall not be used as rinses. Mechanical action with a cloth or brush may be needed to remove stubborn contamination. Care shall be taken when using mechanical action to avoid scratching the Teflon surface of the bailer.
 - b.) The bailer shall be thoroughly rinsed with tap water.
 - c.) The bailer shall then be triple rinsed with deionized/distilled water.
 - d.) The bailer is allowed to air dry or wiped dry using a clean and dry laboratory grade disposable wipe such as a Kimwipe (TM) or equivalent.
 - e.) After the bailer has dried, it shall be wrapped in clean aluminum foil and placed in a clean plastic bag. It is now ready for use again in the field.
 - f.) The same cleaning procedures shall be followed for the cord

utilized in the activity. As an alternative, the cord may be disposed.

VIII. Pump Removal, Certification and Replacement

It may be required from time to time to take pumps out of the system and replace them with new ones. Dedicated pumps shall be removed and placed in a new well only if they can be certified to be clean and operational. A dedicated pump needing maintenance may later be placed back in the same well without the cleaning described below. The following procedures are required to remove the pump and to certify that it is clean and fully operational:

A. Pump Removal

- o Pumps shall be removed from the old well casing as per the instructions found in section IV-E. (Total depth measurements)
- o After the pump and tubing have been removed and placed in the plastic bag, it shall be securely packaged in a shipping carton or clean plastic bag and taken to a controlled environment for repair, or it can be sent to The Laboratory or manufacturer. The dedicated pump may be repaired and cleaned at the facility if it will be placed in the well from which it was retrieved.

B. Pump cleaning

- o After receipt, the pump will be disassembled according to the manufacturer's instructions and using protective gloves.
- o After disassembly, all parts coming in contact with ground water will be washed according to the following protocol:
 - a. Wash with a strong laboratory soap such as Alconox (preferred) or Hexane/Acetone (however, the use of these solvents should be avoided unless absolutely necessary).
 - b. Rinse with tap water.
 - c. Triple rinsed with deionized/distilled water.

C. Reassembly

- o While the pump is still wet the pump shall be carefully reassembled.

Clean vinyl gloves shall be worn from this point forward, whenever the pump is handled.

- o Any parts that appear to be worn shall be replaced with original manufacturer's parts.
- o Tubing shall be washed according to the specifications for the pump or discarded.

D. Certification

- o The pump shall be certified to perform according to original manufacturer's specifications by placing the pump in a tub of deionized/distilled water and starting the pump controller. The pump shall meet or exceed the volume flow specification as per the manufacturer. If the pump does not pass, the appropriate parts shall be replaced. The testing shall be repeated until the flow requirements are met or the pump will be discarded.
- o The purchase of new pump(s) meeting the above operational criteria shall be confirmed contaminate free and certified by the manufacturer. Pump(s) shall come shipped in clean packaging so that no surface is exposed.
- o When the operational criteria have been met, the pump shall be certified to be "contamination free" by allowing a minimum of ten gallons of the deionized/distilled water to flow through the tubing and pumping mechanism. After the ten gallons have passed through the pump, a series of samples shall be collected as per the sampling and analysis plan section V-B. Concurrent with the pump samples, a set of samples from the feed water will also be taken. Certification will occur if all parameters in the pump samples are equal to or less than those of the feed water or show positive parameter values no greater than twice the analytical detection limit of that analyte. The detection limit is generally less than the PQL. Therefore, the above leeway is stated to assure that no residual contamination causes unnecessary additional work. If any analyses are detected above the established control limits, the pump will be disassembled and the cleaning process will be repeated.

- o Tubing

To be reused, tubing shall also be certified as above.

- o Packaging

Following the sampling for certification, the pump (and tubing) shall be carefully wrapped in clean aluminum foil. Extreme care in wrapping the tubing and pump parts shall be taken so that no surfaces remain exposed. After wrapping in aluminum foil, the pump shall be placed in a clean plastic bag and held until the completion of the certification analysis.

- o Pump Return

Following acceptable completion of the certification process, the wrapped, bagged pump (and tubing) shall be carefully placed in a shipping carton and sent back to the facility for installation.

- o Installation

The pump shall then be installed in the well casing following the manufacturer's recommendations and following the methods as found in section IV-E. A minimum of ten liters of well water shall be flushed through the pump before any samples for analysis are taken.

APPENDIX A

APPENDIX A IMMISCIBLES

I. Introduction

The technique used to detect immiscibles in a groundwater monitoring system shall be a gross visual method and can be used to evaluate significantly high concentrations (exceeding water solubility limits) of lighter-than and heavier-than-water contaminants in the system. Modern analytical techniques have the potential ability to detect potential immiscible contaminants long before they can be observed through this visual method.

Sampling wells during a well purge cycle (three full well volumes removed or well purged to dryness) can effectively detect both lighter and denser than water immiscibles.

II. Ranges and Types of Immiscibles

There is a broad range of essentially non-water-soluble liquid chemicals. This range of chemicals can be materials as non-toxic as vegetable oil to highly toxic chlorinated solvents. These compounds can range in true solubilities from less than a part per million to percentage ranges. These compounds can come from natural sources such as crude oils, but normally have an anthropogenic (i.e. man made) source.

A small generic list of lighter and denser compounds is as follows:

Lighter than water (less dense)

Compound	Solubility at 20° C (distilled water)
Hexane (component of gasoline)	9.5 PPM
Benzene	1780 PPM
Toluene	515 PPM
Xylene	175 PPM
Ethylether	69,000 PPM

Heavier than water (more dense)

Compound	Solubility at 20° C (distilled water)
----------	---------------------------------------

Chloroform	8,000 PPM
Methylene chloride	20,000 PPM
Tetrachloroethylene	150 PPM
Carbon Tetrachloride	1,160 PPM

III. Problems and Limitations

The primary limitation for the visual evaluation of immiscibles the need to have the pump screen set so that water can be withdrawn from both the top and the bottom of the water column. The screen shall be set significantly above the bottom of the well, denser immiscibles can not be observed and if the water column can not be drawn down faster than the well recharges so that the top of the water column moves into the screened part of the casing less dense immiscibles can not be detected.

A second problem is the need for visual observation. If very low concentrations of immiscibles are present the ability to detect them separate from the water may be very difficult for the person responsible for this observation.

IV. Alternatives to Immiscible Evaluation

The primary problem with using immiscible analysis for the identification of groundwater contamination is the overall gross aspect of the technique. As seen in the table on the previous page, concentrations will need to be at least five orders of magnitude greater than environmental concern to be detected. Current screening techniques such as TOC (total organic carbon) has a detection limit of approximately one part per million and may be able to detect hydrocarbon contamination long before it can be visually detected. TOX (total organic halides) can detect compounds at a level of 0.01 ppm, a level significantly below any chlorinated compounds solubility. Both of these techniques may be well suited for general water quality evaluation. Even lower detection limits for target analyses can be achieved by either GC or GC/MS analysis using purge-and-trap concentration technology.

Attachment VII-2 Tables

GRASSY MOUNTAIN GROUNDWATER SAMPLING FIELD DATA SHEET
(subject to additions and reformatting without prior notice)

Monitor Well _____ Casing Length _____ ft.

Purge

Personnel _____

Date _____ Time _____ / _____ Apron - Wet/Dry _____

Dedicated Pump - Y/N _____ Locks - Y/N _____ Tamper - Y/N _____ Odor - Y/N _____

Temp _____ Wind _____ Baro. _____ General _____ Time _____

OVA: Background: _____ WH: _____

Water Levels: 1. _____ @ _____ Well Dia. _____

2. _____ Vol. Mult. (liters only): 2.47 (4 inch) / 0.617 (2 inch)

One Volume = _____ G/L 3 Vol. = _____ G/L

Actual Purge Vol. = _____ G/L Turbidity (NTU) _____

Immiscibles Detected : _____ Y/N

Sample

Personnel _____

Date _____ Time _____ / _____ Apron - Wet/Dry _____

Temp _____ Wind _____ Baro. _____ General _____ Time _____

OVA: Background: _____ WH: _____

Flow Rate (ml/min) _____ / _____ Turbidity (NTU) _____

Calibration: pH _____ = _____ ; pH _____ = _____ ; pH _____ reads _____

Sp. Cond. _____ = _____

_____ = _____

Turbidity: 0-10: _____ 10-100: _____ 100-1000: _____

Immiscibles Detected: _____ Y/N

Temp.(°C)

pH

Cond.

2

3

4

Samples:

Well Check

Change in pumping Rate Y/N (Yes, Check Pump and Trap)

Sand or Silt Y/N (Yes, Check Trap)

Casing Cracked or Broken Y/N (Yes, Notify DEQ/DSHW)

Pump Removable Y/N/na (No, Notify DEQ/DSHW)

QA/QC Samples:

Sample Splits: